



ATTACHING END AND MIDDLE PANELS TO WALL CORE

Tools Required:
Socket Set with 9/16" Socket
9/16" Combination Wrench

Hardware Included in PUEF-KIT A
Included with End Panel:
1 Nut, 3/8 -16
1 HHCS, 3/8 -16 x 2-1/2", grade 5
1 Washer, Lock 3/8"
1 Washer, 3/8"
2 Filler Clip

1. Install the HHCS, 3/8-16 x 2-1/2", grade 5 (A) shipped with the core at the bottom of the upright (see Detail A) with the head on the outside of the core, through the filler clip (B), core upright (C), floor clamp and floor clamp angle with the lock washer and nut on the inside.
2. Install the HHCS, 3/8-16 x 2-1/2", grade 5 (E) supplied with this kit at the mid-height of the upright (see Detail B), with the head on the outside of the core through the filler clip (B), flat washer and then into the core upright (C) with lock washer and nut on the inside.
3. Attach the end panel (H) by engaging the tab at the top of the end panel with the slot (G) at the top of the upright (C) and then slide it down along the face of the upright engaging the two filler clips (B).
4. Attach the middle end panel (J) by locating the slots at the bottom of the panel (K) and position it to engage the flange (L) on the core and then rotating the panel vertically to engage the fasteners (M). The top of the middle end panel will be flush with the top of a 1" thick work surface.

